

ARIZONA FORENSIC BREATH ALCOHOL ANALYTICAL REPORT

INSTRUMENT INFORMATION

Analytical Instrument: Intoxilyzer 9000
Serial Number: 90-004605
Software Version: 9439.01.00
Analytical Report Number: 46050430260875

QAS: JOHNSON, ERIK
QAS Permit #: 30455
Agency: GOODYEAR PD
Last 31-Day Check: 04/30/2026
Last Annual Maintenance: 06/16/2025

SUBJECT INFORMATION

Name: 31-Day Check
Test Date: 04/30/2026
Driver's License #:
Gender:
Date of Birth:
Age:

Weight:
State of Issue:
Driver's License Expiration:
Deprivation Start Time: 01:30
15 - Minute Deprivation: Yes

OPERATOR INFORMATION

Name: JOHNSON, ERIK
Agency: GOODYEAR PD

Permit #: 30455

STANDARD INFORMATION

Standard Value: 0.100
Standard Lot #: 28424100A1
Expiration Date: 11/05/2026
Bottle #: 025
Last Changed By: MIYAZATO, KORY

Permit #: 30215

RESULTS

EXCEPTION MESSAGES

* Deficient Sample
** Invalid Sample - Begin new deprivation period
*** RFI Detect

OPERATOR COMMENTS

Test	g/210L	Time
Air Blank	0.000	03:04:56
Diagnostic Test	PASS	03:05:33
Air Blank	0.000	03:06:10
Calibration Chk	0.101	03:06:31
Air Blank	0.000	03:07:11
Subject Test 1	DEF*	03:10:24
Air Blank	0.000	03:11:12
Air Blank	0.000	03:11:53
Subject Test 2	0.000	03:12:21
Air Blank	0.000	03:13:02
Wait		03:17:06
Air Blank	0.000	03:17:44
Subject Test 3	INV**	03:18:16
Air Blank	RFI***	03:18:28

*Deficient Sample
**Invalid Sample - Begin new deprivation period
***RFI Detect

Not a Successfully Completed Test Sequence

*All air blank results must be 0.000.
Consecutive subject test results must not differ by more than 0.020 g/210L.
Standard check results must be $\pm 10\%$.*

EXHIBIT I-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
INTOXILYZER MODEL 9000

PERIODIC MAINTENANCE AND STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST E. JOHNSON #1187 AGENCY GOODYEAR PD
DATE 04-30-2026 TIME 0305
INTOXILYZER SERIAL # 90-004605

- ☒ 1. Ensure that gas tank is attached and contains a standard alcohol concentration 0.100 AC

DIAGNOSTIC TESTS

- ☒ 1. Clock time check
☒ 2. Date check

OPERATIONAL TESTS

- ☒ 1. Deficient Subject Test (Proper Sample Recognition)
Deficient Sample printed
- ☒ 2. Alcohol-free Subject Test (Proper Sample Recognition):
0.000 AC
- ☒ 3. Mouth Alcohol Subject Test (Proper Sample Recognition):
Invalid Sample – Begin new deprivation period printed
- ☒ 4. Radio Frequency Interference Test (Error Recognition):
RFI Detect printed
- ☒ 5. Standard Calibration Check:
0.101 AC
- ☒ 6. Air Blanks Completed
- ☒ 7. Timer Reset

Not a Successfully Completed Test Sequence will be printed

Instrument is operating properly and accurately. YES ☒ NO ☐

COMMENTS:

SIGNATURE ERIK JOHNSON
Digitally signed by ERIK JOHNSON
Date: 2026.04.30 03:19:29 -07'00'